# Sommario

**Comandi per 123Solar** ..... 3
**Aurora** ..... 3
***Link*** ..... 3
***Testare Aurora*** ..... 3
***Manuale*** ..... 3

# Comandi per 123Solar

# Aurora

## Link

Autore Curtronics
Download versione 1.9.0

## Testare Aurora

```
aurora -a 2 -k 364 -Y 3 /dev/ttyUSB0
aurora -a 2 -p -n -f -g -m -v -Y3 /dev/ttyUSB0
```

Aggiornamento manuale 123solar =====

## Manuale

v1.8.7

Uso:

```
aurora [Opzioni] Device
```

Opzioni:

```
-A, --last-alarms              Get last four alarms (once displayed FIFO queue is
cleared)
-b, --verbose                  Verbose mode. For maximum effectiveness should be
the first option
                                  on the command line
-C, --calc-value=<num[:$]>     Calculate monetary value using <num> * kWh. ":$" is
optional and if
                                  included the character(s) represented by the "$"
will be used to
                                  denote monetary type in the output. Defaults to
"$"
-c, --columnize                Output data in columns --> for -d, -e, -D, -3, -E, -
t, & -T options
                                  only will disable any other options -- if value
ends with an
                                  "*" reporting of that item may not be in
inverters firmware
-d <num>, --get-dsp=<num>      Get DSP data <num> indicates string to get data for.
0 indicates both
                                  1 for only string 1, 2 for only string 2. <num>
```

```
is required for
                                   short option and <num> is optional for long
option and if omitted
                                   for long option data for both input strings will
be retrieved
-D, --get-dsp-extended         Get more DSP data
-3, --get-dsp-3phase           Get 3-Phase DSP data
-e, --get-energy               Get Cumulated Energy readings (Excluding Central)
-E <num>, --get-energy-central=<num>  Get Cumulated Float Energy readings
(Central&TRIO only) <num> days
                                   1 to 366 Default 366 <num> is required for short
option and optional
                                   for long option
-f, --firmware-ver             Query for Firmware Version string
-g, --mfg-date                 Query for Inverter Manufacturing Date
-h, --help                     This text
-i, --get-count=<bitmask>      Display Inverter Time Counters <bitmask> is required
for short option
                                   is optional for long option and if omitted for
long option then all
                                   counters will be displayed and Partial counter
will be reset
                                   1 = "Total Run Time"    4 = "Grid Connection
Time"
                                   2 = "Partial Run Time"  8 = "Reset Partial Run
Time"
-j, --get-joules               Display Energy cumulated in the last 10 seconds
-K, --use-kmult=<num>          Adjust vaules reported by -k, --daily-kwh by "<num>"
multiplier
-k <num>, --daily-kwh=<num>    Get past daily kWh for <num> days (1-366)
                                   <num> is required for short option and optional
for long option
                                   and if omitted for long option then all 366 days
or as many that
                                   are found will be displayed
-L <num>, --adjust-time=<num>  Automatically adjust the inverter time if it differs
from the
                                   computer time. If <num> is 0 (zero) do a Daylight
Savings Time
                                   check. If <num> is>= 1 change the inverter time
if it differs
                                   by <num> or more seconds. See the README for more
information
                                   and constraints
-l <num>, --read-wait=<num>    Timeout for the read to the serial port. <num> in
1/10ths seconds.
                                   Default is 1 (0.1 sec). See the README file for
important
                                   information on this option
-M <num>, --max-runtime=<num>  Maximum amount of time in seconds that aurora will
run trying to
                                   get data from the inverter
-m, --get-conf                 Query for Inverter System Configuration
-n, --serial-number            Query for Inverter Serial Number
-N <num>, --central=<num>      Indicates Aurora Central ** Experimental **
                                   0 indicates Master, 1 indicates Slave
```

```
-o, --output-file=<filename>   Append data to file (Created if nonexistant) Note:
If -c option is
                                  used only -d, -e, -D, -3, -E, -t, & -T options
will output to file
-O, --part-number-central      Query for Inverter Part Number (Central only)
-p, --part-number              Query for Inverter Part Number
-P <num>, --comm-pause=<num>   Wait <num> us between sending commands to inverter
(1-1000000)
-Q, --use-qmult                Use inverter specific multiplier if known to adjust
values reported
                                  by -q, --energy-sent
-q <num>, --energy-sent=<num>  Get past energy delivered to the grid **
Experimental **
                                  in 10 second intervals for <num> minutes
(1-1440). <num> is
                                  optional for long option and if omitted all data,
~24 hours
                                  worth will be reported. It is suggested the -Y
option be used
                                  with this due to the extensive length of time
this could take.
                                  See the README file for important information on
this option
-R <num>, --read-timeout=<num> Serial port read retry timeout value when reading a
character from
                                  the Inverter (mS - minimum 200) See the README
file for
                                  important information on this option
-r, --calc-grid-power          Calc Grid power using Grid Voltage * Grid Current,
instead of
                                  reporting the Inverter's value. --> for -d option
only,
                                  ignored when used with -c option (Inverter
typically reports a
                                  lower value. This affects Inverter conversion
efficiency value.)
-S, --set-time                 Set Inverter Date/Time to system time
-s, --get-state                Get Inverter State
-T, --get-loctime              Display computer Date/Time
-t, --get-invtime              Display Inverter Date/Time
-V, --version                  Aurora communications program version
-v, --inv-version              Query for Version string
-U <num>, --read-pause=<num>   Pause <num> milli-seconds after sending command to
inverter before
                                  reading response from inverter (1-10000)
-u, --rpt-read-pause           Report when/that pausing before read
-W, --swap-endian              Swap Endianness
-w <num>, --lock-wait=<num>    Seconds to wait to lock serial port. (1-30)
-X, --rts-cts                  Enable RTS/CTS on the serial port.
-x, --xon-xoff                 Enable XON/XOFF on the serial port.
-Y <num>, --retries=<num>      Retry failed communications with inverter up to
<num> times (1-100)
-y, --rpt-retries              Report the number of retires done
```

Parametri obbligatori

```
-a <num>, --address=<num>      Inverter address. 1-31 on older inverters, 1-63 on
newer inverters.
Device                         Serial Device.
```

Fonte:
**Wiki - Progetti**

Autore:
**Walter62**

Ultimo aggiornamento: **2023/05/04 01:28**